

Table of Contents

O V E R V I E W	III
How To Use This User Guide	III
Assumptions	III
User Guide Contents	III
Installation Process Overview	III
Developing Your Application	IV
Installation Preparation	IV
Related Publication	IV
CHAPTER ① INTRODUCTION	1
Product Description	1
DM & DR Series Motors	1
SR & SD Series Driver	1
Product Features	1
Interface Options	2
Theory of Operation	2
CHAPTER ② GETTING STARTED	5
What You Should Have	5
Drive/Motor Configuration	5
Check-Out Procedure	6
Bench Test	6
CHAPTER ③ INSTALLATION	11
Environmental Considerations	11
Complete System Configuration	11
Drive Mounting	11
DR/DM Motor Mounting	13
Operation Cautions	14
Preparation for Operation	14
Factory Jumper Settings	15
Control Mode Jumper settings	15
Velocity Signal Filter Setting/JP1	16
Feedback & Position Pulse Resolution Settings/JP1	16
Velocity Loop Gain	17
Origin (2-Channel) Pulse Output Signal Setting/JP23	17
Positioning Completion Width Setting/S1	18
Notch Filter Board	18
Wiring Cables	19
Wiring Cautions	20
Motor/Drive Connection	20
Indexer/Drive Connection	23
Input and Output Signals	25
Compliance Control Gain Setting	26
DC Gain Scaling Setting	27
Power ON/OFF	27
CHAPTER ④ CONTROL MODE & ADJUSTMENT	29
Position Control Mode Adjustment	29
I-PD Type Position Control	29
P Type Position Control	30
Position Control System Adjustment Procedure	30
Procedure for Adjustment without Measuring Instruments	31
Setting The Dynaserv Controls	32
Velocity Control Mode Adjustment	34
Torque Control Mode Adjustment	35
CHAPTER ⑤ HARDWARE REFERENCE	37
General Specifications	37
DR Series	37
DR5000 Series	38
DM Series	38
DR5000 Motor Performance	39

DR Motor Performance	40
DR Series—Motor Data	41
DM Series Motor Performance	42
DM Series Motor Performance	42
Dimensional Specifications	43
DR-B Series	44
DR-B Series (for the DR1008B only)	44
DRC Series	44
I/O Signals Between Motor and Driver	46
CHAPTER ⑥ MAINTENANCE & TROUBLESHOOTING	47
Problem Isolation	47
Motor Maintenance and Inspection	47
Resolving Motor Trouble	48
Driver Maintenance and Inspection	48
LED Displays	48
Procedure for Error Correction	49
Returning the System	52
Reducing Electrical Noise	53
Direct Drive Motors & Resonance	53
Resonance Measurement Methods	54
Resonance Counter Measures	54
Resonance Compensation Filters	54
Resonance Analysis Example	57
Eliminating Resonance	57
Resonance Tuning	57
Torque Constant and F/V Gain	58
INDEX	61

O V E R V I E W

How To Use This User Guide

This user guide is designed to help you install, develop, and maintain your system. Each chapter begins with a list of specific objectives that should be met after you have read the chapter. This section should help you find and use the information in this user guide.

Assumptions

This user guide assumes that the user has a fundamental understanding of computers, basic electrical concepts, basic motion control concepts, and basic serial communication (RS-232C) concepts.

User Guide Contents

This user guide contains the following information.

Chapter ① Introduction

This chapter provides a description of the product's basic functions, features, and theory of operation.

Chapter ② Getting Started

This chapter lists items you should have received with your shipment. A basic checkout procedure is provided.

Chapter ③ Installation

This chapter contains system mounting and wiring instructions. Upon completion of this chapter, your system should be completely installed and ready to perform basic operations.

Chapter ④ Control Mode & Adjustment

This chapter provides additional information that will help you customize the system to meet your application's needs. Important application considerations are discussed. Sample applications are provided.

Chapter ⑤ Hardware Reference

This chapter contains system performance specifications (torque/speed curves) and motor dimension specifications.

Chapter ⑥ Maintenance & Troubleshooting

This chapter describes system maintenance procedures. Methods for isolating and resolving problems are provided. Diagnostic error codes are listed.

Installation Process Overview

To ensure trouble-free operation, you should follow the installation procedures outlined in this user guide. Pay special attention to the environment in which the Dynaserv will operate, the layout and mounting, and the wiring and grounding practices used.

Developing Your Application

Before you develop and implement your application, there are several issues that you should consider.

- ① Clarify the requirements of your application. Clearly define what you expect the system to do.
- ② Assess your resources and limitations. This will help you find the most efficient and effective means of developing and implementing your application.
- ③ Follow the guidelines and instructions outlined in this user guide. Proper installation and implementation can only be ensured if all procedures are completed in the proper sequence.

Installation Preparation

Before you attempt to install this product, you should complete the following steps. Successful completion of these steps should prevent subsequent performance problems and allow you to resolve any potential system difficulties before they affect your system's operation.

- ① Become familiar with the user guide's contents so that you can find information that you need quickly.
- ② Develop a basic understanding of all system components, their functions, and interrelationships.
- ③ Complete the basic system configuration and wiring instructions (in a simulated environment, not a permanent installation) provided in *Chapter ② Getting Started*.
- ④ Perform as many basic moves and functions as you can with the preliminary configuration. Try to simulate (with no load attached) the task(s) that you expect to perform when you permanently install your system.
- ⑤ After you have familiarized yourself with and/or tested the system's functions and features, carefully read *Chapter ③ Installation*.
- ⑥ Begin the installation process. Do not deviate from the sequence or installation methods provided.
- ⑦ Before you begin to customize your system, check the system functions and features to ensure that you have completed the installation process correctly.

Related Publication

For more information on motion control concepts and Compumotor's complete product line and product capabilities, refer to the current *Parker Compumotor Motion Control Catalog*