

TABLE OF CONTENTS

How To Use This User Guide	vii
Assumptions	vii
Contents of This Manual	vii
Installation Process Overview	viii
Developing Your Application	viii
Installation Preparation	viii
Related Publications	viii
Chapter ①—Introduction	1
Product Description	1
Features	1
Chapter ②—Getting Started	3
What You Should Have	3
High-Power and Low-Power Drives	3
Quick Test	3
Attach the Motor	5
Quick Test with Indexer	6
Chapter ③—Installation	9
Installation Precautions	9
Environmental Considerations	9
Wiring Considerations	9
Preventing Electrical Noise Problems	10
DIP Switches	11
Installation Overview	12
Series vs. Parallel Motor Wiring	13
Motor Heating	13
Motor Configuration	13
Compumotor Motors—Drive/Motor Connection	13
9-Pin Motor Connector	17
Compumotor Motors—Setting Motor Current	18
Non-Compumotor Motors Drive/Motor Connection	19
Wiring Configurations	19
4-Lead Motor	19
6-Lead Motor	19
8-Lead Motor	20
Parallel Configuration	20
Series Configuration	20
Terminal Connections	21
Non-Compumotor Motors—Setting Motor Current	22
Drive Configuration	24
Automatic Standby Function	24
Motor Resolutions	24
Motor Waveforms	25
Automatic Test Function	25

Drive/Indexer Connection	26
Step & Direction Signal Specification	26
Shutdown & Set Zero Phase Signal Specification	26
Fan Connection	27
AC Power Connection	27
Transformers	28
S: Series Configuration P: Parallel Configuration	28
Testing the System	30
Drive Mounting	31
Minimum Width	31
Minimum Depth	31
Motor Mounting	32
Attaching the Load	33
Couplings	33
Tuning	34
Resonance	34
Mid-Range Instability	34
Tuning Procedures	34
Gauging Motor Resonance	35
Motor Waveforms	36
Rotary vs. Linear Indexers	37
Chapter ④—Hardware Reference	39
Environmental Specifications	39
Electrical Specifications	39
Input Power	39
Output Power	39
Output Type	39
Fault Output	39
Minimum Motor Winding Inductance	39
Maximum Motor Winding Inductance	40
Minimum Motor Hipot	40
Step & Direction Signal Specification	40
Step Pulse Input	40
Direction Input	40
Shutdown & Set Zero Phase Signal Specification	40
Shutdown Input (Amplifier Disable)	40
Set Zero Phase Input	40
Fault Output	40
Operational Specifications	41
Repeatability	41
Hysteresis	41
Rotor Inertia	41
Drive Dimensions	42
Motor Dimensions	43
DIP Switch Summary	47
Motor Performance Specifications	49

Chapter ⑤—Troubleshooting	51
Maintenance	51
Drive Maintenance	51
Motor Maintenance	51
Reducing Electrical Noise	51
Problem Isolation	52
Front Panel LEDs	52
Common Problems and Solutions	53
Testing the Motor	54
Returning the System	54
Appendix—LVD Installation Instructions	55
Complying with the Low Voltage Directive (LVD)	55
Additional Installation Procedures for LVD Compliance	55
Environmental Conditions	55
Electrical	55
Mechanical	56
Servicing the S Drive	56
Thermal Safety	57
Sonic Pressure	57
Table of Graphic Symbols and Warnings	57
Index	59

How To Use This User Guide

This User Guide is designed to help you install, develop, and maintain your system. Each chapter begins with a list of specific objectives that should be met after you have read the chapter. This section is intended to help you find and use the information in this User Guide.

Assumptions

This User Guide assumes that you have the skills or fundamental understanding of the following information.

- Basic electronics concepts (voltage, switches, current, etc.)
- Basic motion control concepts (torque, velocity, distance, force, etc.)

With this basic level of understanding, you will be able to effectively use this User Guide to install, develop, and maintain your system.

Contents of This Manual

This User Guide contains the following information.

Chapter ① Introduction

This chapter provides a description of the product and a brief account of its specific features.

Chapter ② Getting Started

This chapter contains a detailed list of items you should have received with your S Drive shipment. It will help you to become familiar with the system and ensure that each component functions properly.

Chapter ③ Installation

This chapter provides instructions for you to properly mount the system and make all electrical connections. Upon completion of this chapter, your system should be completely installed and ready to perform basic operations. Tuning considerations and procedures are also provided.

Chapter ④ Hardware Reference

This chapter contains information on system specifications (dimensions and performance). It may be used as a quick-reference tool for proper switch settings and connections.

Chapter ⑤ Troubleshooting

This chapter will help you identify and resolve system problems.

Installation Process Overview

To ensure trouble-free operation, pay special attention to the environment in which the S Drive equipment will operate, the layout and mounting, and the wiring and grounding practices used. These recommendations are intended to help you easily and safely integrate S Drive equipment into your manufacturing facility. Industrial environments often contain conditions that may adversely affect solid-state equipment. Electrical noise or atmospheric contamination, may also affect the S Drive System.

Developing Your Application

Before you attempt to develop and implement your application, there are several issues that you should consider and address.

- ① Recognize and clarify the requirements of your application. Clearly define what you expect the system to do.
- ② Assess your resources and limitations. This will help you find the most efficient and effective means of developing and implementing your application.
- ③ Follow the guidelines and instructions outlined in this user guide. Do not skip any steps or procedures. Proper installation and implementation can only be ensured if all procedures are completed in the proper sequence.

Installation Preparation

Before you attempt to install this product, you should complete the following steps:

- ① Review this entire user guide. Become familiar with the User Guide's contents so that you can quickly find the information you need.
- ② Develop a basic understanding of all system components, their functions, and interrelationships.
- ③ Complete the basic system configuration and wiring instructions (in a simulated environment, not a permanent installation) provided in *Chapter ② Getting Started*.
- ④ Perform as many basic functions as you can with the preliminary configuration. You can only perform this task if you have reviewed the entire user guide. You should try to simulate the task(s) that you expect to perform when you permanently install your application (however, do not attach a load at this time). This will give you a realistic preview of what to expect from the complete configuration.
- ⑤ After you have tested all of the system's functions and used or become familiar with all of the system's features, carefully read *Chapter ③ Installation*.
- ⑥ After you have read Chapter ③ and clearly understand what must be done to properly install the system, you should begin the installation process. Do not deviate from the sequence or installation methods provided.
- ⑦ Before you begin to customize your system, check all of the system functions and features to ensure that you have completed the installation process correctly.

The successful completion of these steps will prevent subsequent performance problems and allow you to isolate and resolve any potential system difficulties before they affect your system's operation.

Related Publications

- Current Parker Compumotor Motion Control Catalog